

Offline Quick Start Guide


There are 12 languages available for translating when offline (no Wi-Fi available):

- Chinese
- Dutch
- English
- French
- German
- Indonesian
- Italian
- Japanese
- Korean
- Portuguese
- Russian
- Spanish

To access this, swipe on the interface to the right past the menu settings.

When the Microphone button is pressed on the front, the screen will default to the main translation screen. Keep swiping to the right through the following:

Translations screen -> Picture Translations -> Settings Display -> Settings Menu -> Multimedia -> **Offline Translator** -> Learn (7 options)



Then the desired languages are selected. See photo.



Stay on this screen (DO NOT go back to the default translation screen as that will require Wi-Fi). On this screen, press the microphone button and begin to speak in the selected language, front button for top language and back button for bottom language selection.

The learn modes can also be utilized offline without Wi-Fi. In the Settings Menu, select the Learn option and select the language you want to learn in (38 languages). See photo.



Then scroll past the Offline Translator into any of the Learn modes:

- Alphabet / Numbers
- Time / Months / Days
- Fruit / Veggies / Drinks
- Food / Body Parts / Shapes
- Clothes / Forms of Transport / Animals
- Sports / Instruments / Park Objects

All the above can be done with Wi-Fi Off.